


BQTR ASSEMBLY INSTRUCTIONS



PART LIST

- 1 - PEG SLANT ARM
- 2 - UPRIGHTS
- 2 - BOLTS for attaching upright to base
- 1 - BASE with 2 legs attached
- 2 - BASE LEGS not attached
- 6 - HEX NUTS for attaching 2 legs to base

BASE ASSEMBLY

